

GRT INSTITUTE OF ENGINEERING AND TECHNOLOGY, TIRUTTANI - 631209



Approved by AICTE, New Delhi Affiliated to Anna University, Chennai

DEPARTMENT OF COMPUTER SCIENCE AND ENGINEERING

PROJECT TITLE

Traffic Management for Internet of Things (IoT)

COLLEGE CODE: 1103

NAME: D.Suresh

BATCH: 3rd YR, 5th SEM

REG NO.: 110321104051

EMail ID: sureshsrh05@gmail.com

CODING:

```
from tracking.centroidtracker import CentroidTracker
from tracking.trackableobject import TrackableObject
import tensornets as nets
import cv2
import numpy as np
import time
import dlib
import tensorflow.compat.v1 as tf
import os
import threading
def countVehicles(param):
       # param -> path of the video
       # list -> number of vehicles will be written in the list
       # index ->Index at which data has to be written
       tf.disable v2 behavior()
       # Image size must be '416x416' as YoloV3 network expects that specific image size as
input
       img size = 416
       inputs = tf.placeholder(tf.float32, [None, img size, img size, 3])
       model = nets.YOLOv3COCO(inputs, nets.Darknet19)
       ct = CentroidTracker(maxDisappeared=5, maxDistance=50) # Look into
'CentroidTracker' for further info about parameters
```

```
trackableObjects = {} # Dictionary of trackable objects containing object's ID and its'
corresponding centroid/s
       skip frames = 10 # Numbers of frames to skip from detecting
       confidence level = 0.40 \# The confidence level of a detection
       total = 0 # Total number of detected objects from classes of interest
       use original video size as output size = True # Shows original video as output and
not the 416x416 image that is used as yolov3 input (NOTE: Detection still happens with
416x416 img size but the output is displayed in original video size if this parameter is True)
       video path = os.getcwd() + param # "/videos/4.mp4"
       video name = os.path.basename(video path)
       # print("Loading video {video path}...".format(video path=video path))
       if not os.path.exists(video path):
               print("File does not exist. Exited.")
               exit()
       # YoloV3 detects 80 classes represented below
       all classes = ["person", "bicycle", "car", "motorbike", "aeroplane", "bus", "train",
"truck", \
                               "boat", "traffic light", "fire hydrant", "stop sign", "parking
meter", "bench", \
                               "bird", "cat", "dog", "horse", "sheep", "cow", "elephant",
"bear", "zebra", "giraffe", \
                               "backpack", "umbrella", "handbag", "tie", "suitcase", "frisbee",
"skis", "snowboard", \
                               "sports ball", "kite", "baseball bat", "baseball glove",
"skateboard", "surfboard", \
                               "tennis racket", "bottle", "wine glass", "cup", "fork", "knife",
"spoon", "bowl", "banana", \
                               "apple", "sandwich", "orange", "broccoli", "carrot", "hot dog",
"pizza", "donut", "cake", \
                               "chair", "sofa", "pottedplant", "bed", "diningtable", "toilet",
```

trackers = [] # List of all dlib trackers

"tymonitor", "laptop", "mouse", \

```
"remote", "keyboard", "cell phone", "microwave", "oven",
"toaster", "sink", "refrigerator", \
                               "book", "clock", "vase", "scissors", "teddy bear", "hair drier",
"toothbrush"]
       # Classes of interest (with their corresponding indexes for easier looping)
       classes = { 1 : 'bicycle', 2 : 'car', 3 : 'motorbike', 5 : 'bus', 7 : 'truck' }
       with tf.Session() as sess:
              sess.run(model.pretrained())
              cap = cv2.VideoCapture(video path)
              # Get video size (just for log purposes)
              width = int(cap.get(cv2.CAP PROP FRAME WIDTH))
              height = int(cap.get(cv2.CAP PROP FRAME HEIGHT))
              # Scale used for output window size and net size
              width scale = 1
              height scale = 1
              if use original video size as output size:
                      width scale = width / img size
                      height scale = height / img size
              def drawRectangleCV2(img, pt1, pt2, color, thickness,
width_scale=width_scale, height_scale=height_scale):
                      point1 = (int(pt1[0] * width scale), int(pt1[1] * height scale))
                      point2 = (int(pt2[0] * width scale), int(pt2[1] * height scale))
                      return cv2.rectangle(img, point1, point2, color, thickness)
```

def drawTextCV2(img, text, pt, font, font scale, color, lineType,

width_scale=width_scale, height_scale=height_scale):

```
cv2.putText(img, text, pt, font, font_scale, color, lineType)
              def drawCircleCV2(img, center, radius, color, thickness,
width scale=width scale, height scale=height scale):
                      center = (int(center[0] * width scale), int(center[1] * height scale))
                      cv2.circle(img, center, radius, color, thickness)
              # Python 3.5.6 does not support f-strings (next line will generate syntax error)
              #print(f"Loaded {video path}. Width: {width}, Height: {height}")
              # print("Loaded {video_path}. Width: {width}, Height:
{height}".format(video path=video path, width=width, height=height))
               skipped frames counter = 0
              while(cap.isOpened()):
                      try:
                             ret, frame = cap.read()
                             img = cv2.resize(frame, (img size, img size))
                      except:
                             print(total str)
                      output img = frame if use original video size as output size else
img
                      tracker rects = []
                      if skipped frames counter == skip frames:
                             # Detecting happens after number of frames have passes
specified by 'skip frames' variable value
```

pt = (int(pt[0] * width scale), int(pt[1] * height scale))

```
# print("[DETECTING]")
                             trackers = []
                             skipped frames counter = 0 # reset counter
                             np img = np.array(img).reshape(-1, img size, img size, 3)
                             start time=time.time()
                             predictions = sess.run(model.preds, {inputs:
model.preprocess(np img)})
                             # print("Detection took %s seconds" % (time.time() -
start time))
                             # model.get boxes returns a 80 element array containing
information about detected classes
                             # each element contains a list of detected boxes, confidence
level ...
                             detections = model.get boxes(predictions, np img.shape[1:3])
                             np detections = np.array(detections)
                             # Loop only through classes we are interested in
                             for class index in classes.keys():
                                     local count = 0
                                     class name = classes[class index]
                                     # Loop through detected infos of a class we are
interested in
                                     for i in range(len(np detections[class index])):
                                            box = np detections[class index][i]
                                            if np detections[class index][i][4] >=
confidence level:
```

```
# print("Detected ", class_name, " with
confidence of ", np detections[class index][i][4])
                                                    local count += 1
                                                    startX, startY, endX, endY = box[0],
box[1], box[2], box[3]
                                                    drawRectangleCV2(output img, (startX,
startY), (endX, endY), (0, 255, 0), 1)
                                                    drawTextCV2(output img, class name,
(startX, startY), cv2.FONT HERSHEY SIMPLEX, .5, (0, 0, 255), 1)
                                                    # Construct a dlib rectangle object from
the bounding box coordinates and then start the dlib correlation
                                                    tracker = dlib.correlation_tracker()
                                                    rect = dlib.rectangle(int(startX),
int(startY), int(endX), int(endY))
                                                    tracker.start track(img, rect)
                                                    # Add the tracker to our list of trackers
so we can utilize it during skip frames
                                                    trackers.append(tracker)
                                     # Write the total number of detected objects for a given
class on this frame
                                     # print(class name," : ", local count)
                      else:
                             # If detection is not happening then track previously detected
objects (if any)
                             # print("[TRACKING]")
                             skipped frames counter += 1 # Increase the number frames for
```

which we did not use detection

```
# Loop through tracker, update each of them and display their
rectangle
                              for tracker in trackers:
                                      tracker.update(img)
                                      pos = tracker.get position()
                                      # Unpack the position object
                                      startX = int(pos.left())
                                      startY = int(pos.top())
                                      endX = int(pos.right())
                                      endY = int(pos.bottom())
                                      # Add the bounding box coordinates to the tracking
rectangles list
                                      tracker rects.append((startX, startY, endX, endY))
                                      # Draw tracking rectangles
                                      drawRectangleCV2(output img, (startX, startY), (endX,
endY), (255, 0, 0), 1)
                      # Use the centroid tracker to associate the (1) old object centroids with
(2) the newly computed object centroids
                      objects = ct.update(tracker rects)
                      # Loop over the tracked objects
                      for (objectID, centroid) in objects.items():
                              # Check to see if a trackable object exists for the current object
ID
                              to = trackableObjects.get(objectID, None)
```

```
if to is None:
                                     # If there is no existing trackable object, create one
                                     to = TrackableObject(objectID, centroid)
                             else:
                                     to.centroids.append(centroid)
                                     # If the object has not been counted, count it and mark it
as counted
                                     if not to.counted:
                                            total += 1
                                            to.counted = True
                             # Store the trackable object in our dictionary
                             trackableObjects[objectID] = to
                             # Draw both the ID of the object and the centroid of the object
on the output frame
                             object id = "ID {}".format(objectID)
                             drawTextCV2(output img, object id, (centroid[0] - 10,
centroid[1] - 10), cv2.FONT HERSHEY SIMPLEX, 0.5, (0, 255, 0), 1)
                             drawCircleCV2(output_img, (centroid[0], centroid[1]), 2, (0,
255, 0), -1)
                             # Display the total count so far
                             total str = str(total)
                             drawTextCV2(output img, total str, (10, 30),
cv2.FONT HERSHEY SIMPLEX, 0.6, (0, 0, 255), 2)
                      # Display the current frame (with all annotations drawn up to this point)
                      cv2.imshow(video name, output img)
                      key = cv2.waitKey(1) & 0xFF
```

if key == ord('q'): # QUIT (exits)

break elif key == ord('p'): cv2.waitKey(0) # PAUSE (Enter any key to continue)

```
cap.release()
cv2.destroyAllWindows()
print("Exited")

"""

function which will run our code

will write the number of veicles in the list provided
"""

if __name__ == "__main__":

countVehicles("/videos/test.mp4")
```

Logic for setting the time for each signal

OUTPUT:



